



GAS CONVERSION KIT FROM LP TO NG, P/N CKNG-TEBQ

FOR MODELS: TWIN EAGLES GRILLS, TEBQ/TPBQ



1. All gas connections/conversions should be made by a qualified technician and in accordance with local codes and ordinances.
2. Before conducting a conversion to a gas appliance, verify that the main gas is shut off and disconnected from the appliance.
3. Insure that you have the Natural Gas Conversion Kit , as follows:
 - a. P/N 15110-41, Orifice #41, NG, Grill Burner (3 pcs.)
 - b. P/N 15108-50, Orifice #50, Rotis/ Small IR, for TEBQ-30/TPBQ-30, NG (1 pc.)
 - c. P/N 15108-48, Orifice #48, Rotis/ Large IR, for TEBQ-42/TPBQ-42, NG (1 pc.)
 - d. P/N 15303, Regulator, Natural Gas (1 pc.)
 - e. P/N 18351, Label, Conversion, Gas (1 pc.)
4. Replace burner valve orifices.
 - a. Grill Bumer:
 - i. Remove cooking grates
 - ii. Remove briquette trays
 - iii. Remove grill burners
 - iv. Remove grill burner orifices, #53 drill size
 - v. Replace grill burner orifices with #41 drill size
 - vi. Install back the burners, briquette trays & cooking grates. **WARNING! IT IS CRITICAL THAT THE GAS BURNERS ARE PROPERLY INSTALLED**

WITH THEIR ORIFICES INSIDE THE BURNERS AIR SHUTTERS. IF not properly installed, gas may leak outside of the burner that could lead to fire, potential damage to your grill and bodily injury

- b. Infrared Rotisserie Burner
 - i. Remove rear hood cover to expose infrared burner gas orifice
 - ii. Remove rotis burner orifice, as follows:
 1. #57 for TEBQ-30/TPBQ-30
 2. #56 for TEBQ-42/TPBQ-42
 - iii. Replace rotis burner orifice with:
 1. Orifice #50 for 30" grill, TEBQ-30/TPBQ-30
 2. Orifice #48 for 42" grill, TEBQ-42/TPBQ-42
 - iv. Replace rear hood cover.
5. Replace LP regulator with the factory supplied NG regulator.
 - a. Disconnect the regulator and hose from the LP-bottle.
 - b. Remove the brass coupling from grill manifold
 - c. Install regulator directly to grill manifold pipe. Make sure that the arrow mark on the regulator is pointing towards the grill.
 - d. Check for gas leaks using soapy water solution.
6. **NEVER USE THE GRILL WITHOUT FIRST LEAK TESTING THE GAS CONNECTION.**
 - a. Prepare a leak testing solution of sudsy water by mixing in a spray bottle with half liquid soap and half water.
 - b. Confirm that all control knobs are in the "OFF" position.
 - c. Turn the main gas valve supply "ON".
 - d. Apply leak testing solution by spraying on the pipe joints, fittings, and hose.
 - e. A gas leak is detected if;
 - i. there is a faint gas smell and/or
 - ii. growing bubbles appear on any of the connection points and/or hose. **DO NOT** attempt to ignite the grill and **IMMEDIATELY** turn off the gas supply valve.
 - f. When there is a gas leak, call a qualified service technician. **DO NOT** use the grill until the leak is corrected.
7. Calibrate burner low flame setting
 - a. The grill must be hooked up to the gas supply in order to calibrate burner.
 - b. Turn on burner and set to low. At low setting, all ports of the burner must remain lit. If the flames are too high or too low, calibrate burner valve.
 - c. To calibrate burner valve, pull off valve knob. Insert a skinny flat screwdriver into the valve stem.
 - d. Turn the adjusting screw inside the stem clockwise to decrease flame or counter clockwise to increase flame.
 - e. Perform leak test on the valve stem using the soapy water solution.
8. The conversion is complete. Fill up the Conversion Label. Next, paste it next to the original Serial Plate.
9. The unit is ready for installation. Please refer back to the User's Manual to insure safety, proper care and operation.