

REPLACEMENT PARTS LIST – TWIN EAGLES GAS GRILL (CONTINUED)

Item No.	TE Part Number	Description	TEBQ 30G	TEBQ 30R	TEBQ 36G	TEBQ 36R	TEBQ 42G	TEBQ 42R	TEBQ 54R	
64	S21767-3	Heat Deflector, 30	1	1						
65	S21767-36	Heat Deflector, 36			1	1				
66	S21767-4	Heat Deflector, 42					1	1		
67	S21767-54	Heat Deflector, 54							1	
68	S21715-3Y	Front Panel, 30R		1						
69	S21715-36Y	Front Panel, 36R				1				
70	S21715-4Y	Front Panel, 42R						1		
71	S21715-54Y	Front Panel, 54R							1	
72	S21717-3y	Front Panel, 30G	1							
73	S21717-36Y	Front Panel, 36G			1					
74	S21717-4Y	Front Panel, 42G					1			
75	S16196	Illuminated Switch	1	1	1	1	1	1	1	
76	S13154	Knob, Chrome	2	3	3	4	3	4	6	
77	S13122	Knob Insert	2	3	3	4	3	4	6	
78	S13147	Twin Eagles Logo	1	1	1	1	1	1	1	
79	S16192	LED Holder	2	3	3	4	3	4	6	
80	S13128P	Bezel, Knob, Stainless Steel	2	3	3	4	3	4	6	
81	S14121	Bezel Screw	4	6	6	8	6	8	12	
82	S16194	Hood Switch	1	1	1	1	1	1	1	
83	S21757	Hood Switch Bracket	1	1	1	1	1	1	1	
84	S12112	Hood Switch Rod	1	1	1	1	1	1	1	
85	S14232	Retaining Clip	1	1	1	1	1	1	1	
86	S21745-3Y	Drip Pan Assy. (30")	1	1						
87	S21745-36Y	Drip Pan Assy. (36")			1	1				
88	S21745-4Y	Drip Pan Assy. (42")					1	1		
89	S21745-54Y	Drip Pan Assy. (54")							1	
90	S14420	Roller Bearing	4	4	4	4	4	4	4	
91	S12401	Flex Tubing, 3/8 x 48"		1		1		1	2	
92	S16321	Hot surface igniter, Main Burner	2	2	3	3	3	3	4	
93	S21750Y	Flash Tube, (For standard U-Burners ONLY)	2	2	3	3	3	3	3	
94	S21765Y	Flash Tube, (For optional Sear Zone Burners ONLY)	1	1	1	1	1	1	1	
95	S13345	Sear Zone Burner (For optional Sear Zone Burners ONLY)	1	1	1	1	1	1	1	
96	S13144	Screen Mesh (For optional Sear Zone Burners ONLY)	1	1	1	1	1	1	1	
97	S 21743	Zone Divider	1	1	2	2	2	2	3	
98	S 13301	Stainless Steel U6-burner (0.75 in. wall)	2	2			3	3	3	
99	S 13350	Stainless Steel U5-burner (0.75 in. wall)			3	3				
100	S91183Y	Smoker Box Assy.	1	1			1	1	1	
101	S22728Y	Smoker Box, Assy. (36")			1	1				
102	S21761 Y	4 1/2" Briquette Tray Assembly complete with briquettes (Grill w/ Sear Zone) Optional			2	2				
103	S21752Y	6" Briquette Tray Assembly complete with briquettes	2	2			2	2	2	
104	S21753Y	12" Briquette Tray Assembly complete with briquettes (Standard grill)	1	1			2	2	2	
105	S21759 Y	10" Briquette Tray Assembly complete with briquettes (Standard grill)			2	2				
106	S13801	13" Stainless Steel Hex Grate	2	2			2	2	2	
107	S13802	12" Stainless Steel Hex Grate					1	1	2	
108	S13873	10 9/16" Stainless Steel Hex Grate			3	3				
109	S14226	Springs kit, hood	2	2	2	2	2	2	2	
110	S220739	Transformer Cover	1	1	1	1	1	1	1	
111	S16264	Fuse, 15A 250V	1	1	1	1	1	1	1	
112	S16263	Fuse Holder	1	1	1	1	1	1	1	
113	S22038	Transformer Mount	1	1	1	1	1	1	1	
114	S16233	Transformer	1	1	1	1	1	1	1	
115	S16233Y	Transformer Assembly	1	1	1	1	1	1	1	
Non-Shown Parts										
	S13129	Briquettes Only	(48)	(48)	(72)	(72)	(72)	(72)	(72)	
	S16247Y	LED Wire Harness, 30" (NOT SHOWN)	1	1						
	S16248Y	LED Wire Harness, 36" (NOT SHOWN)			1	1				
	S16248Y	LED Wire Harness, 42" (NOT SHOWN)					1	1		
	S16296Y	LED Wire Harness, 54" (NOT SHOWN)							1	